

1. TEE INJECTOR IS THE CONVENTIONAL DESIGN (PARALLEL TO FEEDER SHAFT)
2. RIGHT HAND DOOR SHOWN VIEWING IN DIRECTION OF FLOW.
3. AIR ELBOW NEAR CHECK VALVE IS NOT RECOMMENDED.
4. ON CHIPS AND WET SAWDUST SYSTEMS, ALLOW 15 - 20 FEET AFTER TEE, BEFORE TURNING WITH AN ELBOW.
5. EXTRA HEAVY CONSTRUCTION  
TOP FLANGE OF TEE IS 3/8" PL. ON 6-5/8, 1/2" PLATE ON 8-5/8 AND UP.  
BODY IS 1/4" FOR 6-5/8 & 8-5/8, 5/16" FOR 10-3/4 AND UP
6. FLAT TEE DESIGN REDUCES WEAR ON THE DOWNSTREAM END OF TEE-INJECTOR

